iPod Nano 2nd Generation Top Bezel Replacement

Written By: iRobot



INTRODUCTION

The plastic part on the top of the iPod.

TOOLS:

- iFixit Opening Tools (1)

PARTS:


- iPod Nano Gen 2 Top Bezel (1)

Step 1 — Top Bezel



Before opening your iPod, ensure that the hold switch is in the locked position.

Step 2



- Carefully insert an iPod opening tool in the seam between the metal casing and white plastic top.
- Lift the top bezel off the iPod. It's glued on using a mild adhesive, so some force may be required.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-18 03:33:14 PM.

